

## **OPEL**

Read security code

Switch ignition on

Read security code

Type 1

Immobiliser

Select from vehicle

Agila 00-08

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Astra 95-04

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Astra H

Immobiliser

Erase keys

Program keys

Smart key system

All lost Keys

Program keys

Erase keys

Calibra 95-98

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Combo 98-

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Corsa 95-06

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Insignia

With smart

All smart keys lost

Add a smart key

Erase DTC

Live data

Without smart

All keys lost

Erase DTC

Live data

Meriva 02-

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Movano 98-01

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Omega

Type 1

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Type 2

ECU identification

Program keys

Erase keys

Sintra 97-98

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Tigra 95-02

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Vectra 95-02

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Zafira 99-05

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

Select from type

Type 1

With smart

All smart keys lost

Erase DTC

Live data

Without smart

All keys lost

Erase DTC

Live data

## Type 2

ECU identification

Fault codes

Erase DTC

Live data

Input security code

Input security code

Program function

Program keys

Erase keys

## Type 3

ECU identification

Program keys

Erase keys

## Type 4



Erase keys

Program keys

Remote

Astra-H

Erase remote keys

Program remote key

Corsa-D

Erase remote keys

Program remote key

Zafira-B

Erase remote keys

Program remote key

Vectra-C/Signum

Erase remote keys

Program remote key