

Geely

Select from vehicle

Geely

Jinying

STEC Immobiliser

New Yuanjing

Continental PEPS

Yuanjing

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Ziyoujian

STEC Immobiliser

Gleagle

Xiongmao

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Immobiliser(UAES EMS)

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

GX718

BCM

Lear BCM(KWP2000)

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

GX720

BCM

Continental BCM(CANBUS)

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

GC7

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

PEPS

Steelmate PEPS

Read program result

Reset PEPS

Reset SHL

Program new system

Program SHL

Program PEPS

Program key and Remote

GX7

Immobiliser

STEC Immobiliser

BCM

Lear BCM

PEPS

Hella PEPS

-2015(6 digits pin code)

2015-(32 digits ESK code)

GX9

Immobiliser

STEC Immobiliser

PEPS

Hella PEPS

-2015(6 digits pin code)

2015-(32 digits ESK code)

Emgrand

EC7

Immobiliser

Siemens Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

PEPS

Continental PEPs

-2015(No pin)

Key Number

Key Program

Erase current key

Add 1 key

Add 2 keys

Not erase current key

Add 1 key

Add 2 keys

Other function

PEPS config

ESCL learn

PEPS erase ESK

ESCL erase ESK

After sale mode change

PEPS learn

2015-(32 digits ESK code)

Key Number

Key Program

Erase current key

Add 1 key

Add 2 keys

Not erase current key

Add 1 key

Add 2 keys

Other function

PEPS config

ESCI learn

PEPS erase ESK

ESCL erase ESK

After sale mode change

PEPS learn

EC820

BCM

Lear BCM(KWP2000)

Lear BCM(CANBUS)

Add remote

UAES BCM(UDS)

Program keys

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Mitsubishi Immobiliser

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

PEPS

Steelmate PEPS(4 digits pin code)

Read program result

Reset PEPS

Reset SHL

Program new system

Program SHL

Program PEPS

Program key and Remote

EC825

BCM

Lear BCM(KWP2000)

Lear BCM(CANBUS)

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Mitsubishi Immobiliser

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

PEPS

Steelmate PEPS

Read program result

Reset PEPS

Reset SHL

Program new system

Program SHL

Program PEPS

Program key and Remote

Hella PEPS

-2015(6 digits pin code)

2015-(32 digits ESK code)

EX8

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

EV

PEPS

Continental PEPS

-2015(No pin)

2015-(32 digits ESK code)

EV8

PEPS

Hella PEPS

-2015(6 digits pin code)

2015-(32 digits ESK code)

FC-2

Immobiliser

STEC Immobiliser

GC9

PEPS

Hella PEPS(32 digits ESK code)

GL

BCM

Continental BCM

Immobiliser

STEC Immobiliser

PEPS

GS

BCM

Continental BCM

Immobiliser

STEC Immobiliser

PEPS

HEV

PEPS

Continental PEPS

-2015(No pin)

2015-(32 digits ESK code)

X6

BCM

Continental BCM

PEPS

Naen PEPS

NL-3

PEPS

Maple

Immobiliser

STEC Immobiliser

Englon

SC3

Immobiliser

Immobiliser(UAES EMS)

SC5

Immobiliser

STEC Immobiliser

SC6

Immobiliser

STEC Immobiliser

PEPS

Steelmate PEPS(4 digits pin code)

SC7

Immobiliser

STEC Immobiliser

SX7

BCM

Lear BCM(SX715)

PEPS

Hella PEPS

-2015(6 digits pin code)

2015-(32 digits ESK code)

TX4

Immobiliser

Integrated BCM(Delphi EMS)

Jingang(CROSS)

Immobiliser

STEC Immobiliser

PEPS

Steelmate PEPS(4 digits pin code)

Select from type

Immobiliser

STEC Immobiliser

Lear BCM(KWP2000)

Lear BCM(CANBUS)

Continental BCM(CANBUS)

UAES BCM(UDS)

Mitsubishi Immobiliser

PEPS

Steelmate PEPS(4 digits pin code)

Continental PEPS

-2015(No pin)

2015-(32 digits ESK code)

Hella PEPS

-2015(6 digits pin code)

2015-(32 digits ESK code)