

## **JAC**

### Immobiliser

#### Binyue

##### Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

Tricyclic remote

Heyue A30

MT Type

DIAS Immobiliser(8 digit Pin)

DIAS Immobiliser(4 digit Pin)

CVT Type

BCM

Live data

Program function

Add keys

Erase keys

DIAS Immobiliser(8 digit Pin)

DIAS Immobiliser(4 digit Pin)

JAC J7

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

Tricyclic remote

JAC J3(Turin)

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

DIAS Immobiliser(8 digit Pin)

DIAS Immobiliser(4 digit Pin)

JAC J6

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

DIAS Immobiliser(8 digit Pin)

DIAS Immobiliser(4 digit Pin)

JAC J5

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

DIAS Immobiliser(8 digit Pin)

DIAS Immobiliser(4 digit Pin)

JAC J2

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

DIAS Immobiliser(8 digit Pin)

DIAS Immobiliser(4 digit Pin)

S2

Delphi Immobiliser

DIAS Immobiliser(8 digit Pin)

DIAS Immobiliser(4 digit Pin)

S3

Delphi Immobiliser

DIAS Immobiliser(8 digit Pin)

DIAS Immobiliser(4 digit Pin)

S5

Type 1(1.5T)

Live data

Program new system

Add new key

Add old key

Erase keys

Replace engine ECU

Replace immobiliser ECU

Reset immobiliser ECU

Reset engine ECU

Type 2(Delphi)

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys



Remote

10 PIN

Type 1

Add remote

Type 2

Add remote

16PIN

Hechang

Live data

Program function

Add keys

Erase keys

Heyue

Add remote

Tongyue

Add remote

Binyue

Add remote

Tricyclic remote

S3

Live data

Program function

Add keys

Erase keys

S5

Live data

Program function

Add keys

Erase keys

M3

Add remote

M5

Live data

Program function

Add keys

Erase keys

IEV5

Add remote

PEPS

Heyue A30

CVT Type

PEPS

ESCL learn

Add keys