

GREATWALL

Read security code

STEC immobiliser system

DIAS immobiliser

HELP

Gwperi,M1

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Cowry, V80

Immobiliser

Delphi Petrol Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

Floridi,M4

Immobiliser

STEC Immobiliser

Coolbear,M2

Immobiliser

DIAS Immobilise

Lingao,C20R

Immobiliser

STEC Immobiliser

C10

STEC Immobiliser

C20R

STEC Immobiliser

C30

2011-2014

Immobiliser

STEC Immobiliser

2015

BCM

Add remote

BCM Unlock

KSTAR push button PEPS system

Live data

Change PEPS

Erase K-SK, relearn key(2 keys)

Enter the recovery EOL learning mode

Request to enter the key matching mode

Erase Key-SK

Write Key-SK into base system

Request Base to start matching keys

Writing ECU data into PEPS

Change EMS

Add/Erase smart keys

Replace the solenoid valve

EOL offline mode learning

Brand new matching PEPS and EMS

Not erase K-SK, relearn key(2 keys)

Enter the recovery EOL learning mode

Request to enter the key matching mode

Request Base to start matching keys

C50

2012

STEC Immobiliser

BCM

C50 upgrade(CHB012)

KSTAR push button PEPS system

KSTAR knob type PEPS system

C50 sport(JZ40)

KSTAR push button PEPS system

Wingle

Immobiliser

Delphi Petrol Immobiliser

Delphi Diesel (Bosch 2.8TC) Immobiliser

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

Read engine VIN

Delphi Diesel (Delphi 4D20) Immobiliser

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase list of keys

Replace engine ECU

Replace immobiliser ECU

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Delphi Diesel (Bosch 4D20) Immobiliser

Delphi Petrol Immobiliser(Union)

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase list of keys

Replace engine ECU

Replace immobiliser ECU

Program engine VIN

Reset engine ECU

Reset immobiliser

Delphi Bosch Immobiliser(EDC17C63)

Delphi Diesel (XinFeng 2.8TC) Immobiliser

Wingle5

Delphi Petrol Immobiliser

Delphi Diesel (Bosch 2.8TC) Immobiliser

Delphi Diesel (Delphi 4D20) Immobiliser

Delphi Diesel (Bosch 4D20) Immobiliser

Delphi Petrol Immobiliser(Union)

Delphi Bosch Immobiliser(EDC17C63)

Delphi Diesel (XinFeng 2.8TC) Immobiliser

Wingle6

BCM

Immobiliser

Delphi Petrol Immobiliser

Delphi Diesel (Delphi 4D20) Immobiliser

Delphi Diesel (Bosch 4D20) Immobiliser

Hover H1

BCM

Immobiliser

STEC Immobiliser

Hover H2

PEPS

Hover H3

Immobiliser

Delphi Petrol Immobiliser

Delphi Diesel (Bosch 2.8TC) Immobiliser

BCM

Delphi BCM

Add remote

Tung Thih BCM

Add remote

Hover H5

BCM

Delphi BCM (CAN)

Add remote

Delphi BCM

Add remote

Tung Thih BCM

Add remote

Immobiliser

Delphi Petrol(4G63 MT20) Immobiliser

Delphi Petrol(4G63T MT80) Immobiliser

Delphi Diesel (Bosch 2.8TC) Immobiliser

Delphi Diesel (Delphi 4D20) Immobiliser

Delphi Diesel (Bosch 4D20) Immobiliser

Hover H5 edition

Immobiliser

Delphi Petrol(4G63T MT80) Immobiliser

Delphi Diesel (Bosch 4D20) Immobiliser

Hover H6

2012

BCM

Delphi BCM

UAESi BCM

Immobiliser

Tung Thih Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Program function

Replace engine ECU

Replace immobiliser ECU

Add a new keys

Re-program keys

Erase keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Erase all keys

Reset immobiliser

Reset engine ECU

Program VIN

Check key

Lock immobiliser

STEC Immobiliser

2013

KSTAR knob type PEPS system

KSTAR push button PEPS system

Hover H6 COUPE

PEPS

Key learning (Offline)

Key learning (Sale)

After sales learning

Learning a whole new system

Clear learning status

Clear ESCL

Clear EMS

Clear CAPE

Hover H7

KSTAR knob type PEPS system

KSTAR push button PEPS system

Hover H8

KSTAR push button PEPS system

Live data

Change PEPS

Erase K-SK, relearn key(2 keys)

Enter the recovery EOL learning mode

Request to enter the key matching mode

Erase Key-SK

Write Key-SK into base system

Request Base to start matching keys

Learning solenoid valve

Writing ECU data into PEPS

Change EMS

Program smart keys

Replace the solenoid valve

EOL offline mode learning

Brand new matching PEPS and EMS

Not erase K-SK, relearn key(2 keys)

Enter the recovery EOL learning mode

Request to enter the key matching mode

Request Base to start matching keys

Hover H9

KSTAR push button PEPS system

Live data

Change PEPS

Erase K-SK, relearn key(2 keys)

Enter the recovery EOL learning mode

Request to enter the key matching mode

Erase Key-SK

Write Key-SK into base system

Request Base to start matching keys

Learning solenoid valve

Writing ECU data into PEPS

Change EMS

Program smart keys

Replace the solenoid valve

EOL offline mode learning

Brand new matching PEPS and EMS

Not erase K-SK, relearn key(2 keys)

Enter the recovery EOL learning mode

Request to enter the key matching mode

Request Base to start matching keys