

ZHENGZHOU NISSAN

Read security code

Shuaike 1.6

Immobiliser

MX6

Steering lock release

The control unit is initialized

Mechanical key register

Smart Key Register

Sign steering lock ID

Shuaike 1.5

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Shuaike 1.6

Shuaike 2.0

Ruiqi

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Oting diesel

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Other type

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser