

## **LIEBAO**

CS6

Diesel

Siemens Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Petrol

Siemens Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Replace engine ECU

Replace immobiliser ECU

CS7

Immobiliser

DIAS immobiliser(UAES)

Delphi immobiliser(4G15)

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

DIAS immobiliser(4G18)

Delphi immobiliser(4A15T)

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

jicheng immobiliser(4A15T)

Program PIN

Input PIN

Program new keys

Program old keys

Erase keys

Program VIN

IMMO Rest

Program Date

Diagnosis Date

Program service station ID

EMS Reset

Program EMS

From EMS program IMMO

Offline program IMMO

Aftermarket replacement IMMO

Aftermarket replacement EMS

Aftermarket replacement key

## BCM

Erase Remote

Erase the first remote

Erase the second remote

Erase the third remote

Erase the fourth remote

Erase all remote

Remote learning

Position 1 Learning

Position 2 Learning

Position 3 Learning

Position 4 Learning

## CS4

Immobiliser

jicheng immobiliser(4A15T)

Program PIN

Input PIN

Program new keys

Program old keys

Erase keys

Program VIN

IMMO Rest

Program Date

Diagnosis Date

Program service station ID

EMS Reset

Program EMS

From EMS program IMMO

Offline program IMMO

Aftermarket replacement IMMO

Aftermarket replacement EMS

Aftermarket replacement key

CS10

Immobiliser

jicheng immobiliser(4A15T)(CAN\_BUS)

ECU reset

Write configuration information

Vehicle production date

VIN

Service code

Loading Date

Offline configuration

Aftermarket replacement IMMO or EMS

Aftermarket replacement key

PEPS

Naen PEPS

Keys number

Add a key

Erase keys