

HAWTAI MOTOR

Select from vehicle

Terracan

Remote

10PIN Type 1

Add remote

10PIN Type 2

Add remote

16PIN Type

Add remote

Santa Fe(CHINA)

Immobiliser

Type 1

ECU identification

Fault codes

Erase DTC

Live data

Program function

Read security code

Add a key

Erase keys

Read VIN

Check key

Program immobiliser ECU

Program engine ECU

Type 2

Program keys

ECM neutral

Live data

Remote

10PIN Type 1

Add remote

10PIN Type 2

Add remote

16PIN Type

Add remote

Santa Fe(Import)

Immobiliser

Type 1

ECU identification

Fault codes

Erase DTC

Live data

Program function

Read security code

Add a key

Erase keys

Read VIN

Check key

Program immobiliser ECU

Program engine ECU

Type 2

Program keys

ECM neutral

Live data

Type 3

Program keys

ECM neutral

Live data

Type 4

Program keys

ECM neutral

Live data

Remote

10PIN Type 1

Add remote

10PIN Type 2

Add remote

16PIN Type

Add remote

B11

Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Program function

Read security code

Add a key

Erase keys

Read VIN

Check key

Program immobiliser ECU

Program engine ECU

Remote

16PIN Type

Add remote

B35

Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Program function

Read security code

Add a key

Erase keys

Read VIN

Check key

Program immobiliser ECU

Program engine ECU

Remote

16PIN Type

Add remote

B21

Remote

10PIN Type 1

Add remote

10PIN Type 2

Add remote

16PIN Type

Add remote

Select from type

Immobiliser

Type 1

ECU identification

Fault codes

Erase DTC

Live data

Program function

Read security code

Add a key

Erase keys

Read VIN

Check key

Program immobiliser ECU

Program engine ECU

Type 2

Program keys

ECM neutral

Live data

Type 3

Program keys

ECM neutral

Live data

Type 4

Program keys

ECM neutral

Live data

Remote

10PIN Type 1

Add remote

10PIN Type 2

Add remote

16PIN Type

Add remote