

## **LIFAN\_AUTOMOBILE**

LIFAN Cars

520

Integrated Immobiliser JIK001 (Delphi Engine)

ECU identification

Fault codes

Erase DTC

Live data

Read immobiliser state

Read key code

Program function

Replace engine ECU

Replace immobiliser ECU

Program keys

Reset engine ECU

Reset immobiliser

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Write key number

Program WSC

Write programming Date

Write diagnosing Date

Program engine VIN

Program immobiliser VIN

Integrated Immobiliser JIK009(Sun Tek Engine)

ECU identification

Fault codes

Erase DTC

Live data

Read immobiliser state

Read key code

Program function

Replace engine ECU

Replace immobiliser ECU

Program keys

Reset engine ECU

Reset immobiliser

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Write key number

Program WSC

Write programming Date

Write diagnosing Date

Program engine VIN

Program immobiliser VIN

Siemens Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

620

Integrated ImmobiliserJIK001(Delphi Engine)

Integrated ImmobiliserJIK009(Sun Tek Engine)

Siemens Immobiliser

X60

Integrated ImmobiliserJIK001(Delphi Engine)

Siemens Immobiliser

LIFAN Micro-car

FengShun

Integrated ImmobiliserJIK001(Delphi Engine)

Integrated ImmobiliserJIK009(Sun Tek Engine)

Siemens Immobiliser

XingShun

Integrated ImmobiliserJIK009(Sun Tek Engine)

Siemens Immobiliser

FuShun

Integrated ImmobiliserJIK009(Sun Tek Engine)

Siemens Immobiliser

MaiWei

Match Key

Eraze Key

Match ESCL

Eraze ESCL