

SGMW

310

Immobiliser

Key NO.

Program keys

Erase keys

ECM reset

Program modules

330

Immobiliser

Key NO.

Program keys

Erase keys

510

Immobiliser

Key NO.

Program keys

Erase keys

ECM reset

Program modules

PEPS

Key NO.

Add a key

All keys lost

560

Immobiliser

Key NO.

Program keys

Erase keys

ECM reset

Program modules

PEPS

Key NO.

Add a key

All keys lost

610

Immobiliser

Program keys

Erase keys

Key NO.

Remote

Program remote

Remote NO.

630

Immobiliser

Program keys

Erase keys

Key NO.

Remote

Program remote

Remote NO.

730

Immobiliser

Key NO.

Program keys

Erase keys

ECM reset

Program modules

SGMW Hongguang S1

Immobiliser

Key NO.

Program keys

Erase keys

ECM reset

Program modules