

## **ISUZU**

### Immobiliser

#### D-MAX

Add keys

Erase keys

Erase DTC

#### MU-7

Add keys

Erase keys

Erase DTC

### PEPS

#### D-MAX

Program keys

Erase keys

Reset passive entry and start system control

Reset the ECU

Steering lock ECU reset

Passive entry and start system programming functions

VIN programming

#### MU-X

Program keys

Erase keys

Reset passive entry and start system control

Reset the ECU

Steering lock ECU reset

Passive entry and start system programming functions

VIN programming